


**Models:
LB 4SS
LB 4TR
LB 4EX**



OPERATION AND PARTS MANUAL

Limb Beaver LLC
3566 Robbins Nest Rd
Thompson's Station, TN 37179
844-697-5505
615-707-2278
www.LimbBeaver.com

January 2026

Table Of Contents

1. Introduction.....	3
2. Specifications	4
3. Safety.....	5
3.1 Operation Hazards	5
3.1.1 Do Not Allow Riders	7
3.1.2 Hazards From Modifying Equipment	7
3.2 Maintenance Hazards	7
3.2.1 Lockout/Tagout.....	7
3.3 Safety Decals	8
4. Setup.....	9
4.1 Hydraulic Hoses.....	9
4.2 Wireless Remote (If Equipped).....	9
5. Operation.....	10
5.1 Attach To Carrier	10
5.2 Detach From Carrier	11
5.3 Transporting	12
5.4 Daily Inspections	12
5.5 Operating Limb Beaver	12
5.5.1 Operational Safety.....	12
5.5.2 Machines With Manual Tilt And Swing	14
5.5.3 Machines With Hydraulic Tilt And/Or Swing.....	16
5.5.4 Machines With Wireless Remote	17
6. Maintenance.....	19
6.1 Lubrication	19
6.2 Replace Cutting Teeth Or Drum Bearing	20
7. Troubleshooting	21
8. Parts.....	22
9. Warranty	26

Introduction

1. Introduction

Congratulations on your purchase of a Limb Beaver limb cutter.

Carefully examine the Limb Beaver upon receipt. Report any damage immediately to the freight carrier and register any claim.

Read and understand this manual before using the Limb Beaver and follow all of the safety instructions. Keep this manual with the Limb Beaver at all times.

Read and understand the carrier operators manual before operation and follow all of the safety instructions.

Information provided in this manual was current as of the issue date. Limb Beaver LLC. reserves the right to make design changes without further notice or liability.

This manual explains the operation and routine maintenance of the Limb Beaver.

Information furnished in this manual does not include all of the details of design, production, or variations of the equipment. It does not cover all the possible contingencies, which may arise during operation, setup, or maintenance. Should special issues arise, or further information be desired, please contact Limb Beaver.

The text contained in this manual is for current production models. Some instructions and maintenance procedures may not apply to your specific unit.

Equipment modifications from original design and specifications are strictly prohibited. Modifications or overloading may compromise safe operation of the Limb Beaver, subjecting users to serious injury or death and may void any remaining warranty.

Limb Beaver reserves the right to change, improve, modify or expand features of this equipment at any time. Specifications, models, or equipment are subject to change without notice, and without incurring any obligations to change, improve or expand features of previously delivered equipment. Because of the variations in optional equipment and continued design improvement, certain information contained within this manual may not apply.

This operators manual does not replace, nor does its use release the owner/operator from observing all safety codes or operating limitations as well as any applicable federal, state, provincial or local regulations.

The Limb Beaver is designed to be used by experienced operators, trained in the safe operation of a carrier and trained in the hazards related to using the Limb Beaver, and the safe use of the Limb Beaver for the intended purpose.

Serious injury or death of the operator or bystanders may be caused if the Limb Beaver is misused.

Misuse may also cause damage to the carrier carrying the Limb Beaver.

Operator Orientation - The directions left, right, front and rear, as mentioned throughout this manual, are as seen from the operator's platform and facing in the direction of travel.

Specifications

2. Specifications

Cutting Path.....	48 in.
Rotor Speed	3000 RPM
Cutting Teeth	34
Recommended Hydraulic Flow.....	15-25 GPM
Maximum Limb Diameter.....	4 in.
Weight:	
LB 4SS	950 lbs
LB 4TR	950 lbs
LB 4EX	400 lbs

Safety

3. Safety

Before setting up, operating or servicing the Limb Beaver, you must read, understand and follow the instructions and safety warnings in this manual. Your machine may not be equipped with some of the optional equipment described in this manual.

If you have any safety concerns or questions that are not covered by this manual, please contact Limb Beaver.

The safety information in this manual is denoted by the safety alert symbol:  This symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

The level of risk is indicated by the following signal words:

DANGER

Indicates a hazardous condition that will result in serious injury or death if not performed appropriately.

WARNING

Indicates a hazardous condition that could result in serious injury or death if not performed appropriately.

CAUTION

Indicates a hazardous condition that could result in serious injury if not performed appropriately.

NOTICE

Indicates a situation that could result in damage to the machine or other property.

3.1 Operation Hazards

The following hazards are possible during the operation of the Limb Beaver. All operators, maintenance and service personal, or any one working with or near the Limb Beaver must be familiar all hazards.

DANGER

Prevent electrocution.

Death or serious injury can result if equipment comes near or contacts power lines.

Electrocution can occur without direct contact.

WARNING

Do not operate the Limb Beaver until you read and understand this manual.

WARNING

Do not operate, work on or around Limb Beaver while under the influence of alcohol, prescription or nonprescription medication, or if feeling ill.

WARNING

Entanglement and severing hazard.

Disengage hydraulic flow and allow cutting head to stop before leaving operators seat.

WARNING

Prevent death or serious injury.

Do not exceed carrier rated operating capacity.

Safety

WARNING

Prevent death or serious injury.

Operate the Limb Beaver with a carrier equipped with a Roll-Over Protective Structure (ROPS). The carrier must be equipped with an operator enclosure.

WARNING

Pressurized fluids can penetrate the skin.

Hydraulic hoses can fail from age, damage and exposure.

Use body and face protection while searching for leaks. A tiny, almost invisible leak can penetrate the skin, thereby requiring immediate medical attention.

Use wood or cardboard to detect hydraulic leaks, never use your hands.

WARNING

Wear personal protective equipment appropriate for the job.

WARNING

This product can expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

For more information go to www.P65Warnings.ca.gov/product.

WARNING

Crush hazard.

A raised Limb Beaver can fall, resulting in death or serious injury.

Never enter the area under a raised Limb Beaver.

WARNING

Do not make any alterations to this machine. Altering may cause machine to be unsafe and may void the manufacturers' warranty.

Always use Limb Beaver replacement parts. Not using Limb Beaver parts may void the warranty and/or cause harm to personnel or machine.

WARNING

Safety is the responsibility of the operator.

Verify your carrier's safety features, including ROPs and FOPs meet your job safety requirements.

WARNING

Prevent death or serious injury.

Do not attempt to operate Limb Beaver using forks through forklift pads.

Forklift pads are for handling and storage only.

Safety

NOTICE

Do not use this equipment for any other purpose than it was designed.

Using this equipment for any other purpose could result in damage to equipment or injury to personnel.

Carefully read all safety messages in this manual.

New equipment components and repair parts must include the current safety decal.

Learn how to properly operate this equipment.

Never operate or work around this equipment without proper instruction, while fatigued or under the influence of alcohol, prescription or nonprescription medication, or if feeling ill.

Keep your equipment in proper working condition. Know the regulations and laws that apply to you and your industry. This manual is not to replace any regulations or laws. Additional information may be found at: www.asae.org or www.osha.gov. If you do not understand any part of this manual, contact your Limb Beaver dealer.

3.1.1 Do Not Allow Riders

Never lift or carry anyone on the Limb Beaver. Never use the Limb Beaver as a work platform. Never allow riders on the Limb Beaver.

3.1.2 Hazards From Modifying Equipment

Do not make any alterations to the Limb Beaver. Altering the Limb Beaver may cause unsafe conditions and may void the manufacturer's warranty. Always use Limb Beaver replacement parts.

3.2 Maintenance Hazards

The following maintenance and service hazards are in addition to those found while operating the Limb Beaver. All operators, maintenance and service personal, or any one working with or near the Limb Beaver must be familiar of all hazards. If you do not understand any part of this manual, contact Limb Beaver.

After performing inspections, service or maintenance, all guards must be reinstalled and verify all safety devices are functional.

Wear personal protective equipment appropriate for the job.

Always use Limb Beaver replacement parts. Not using Limb Beaver parts may cause harm to personnel and may void the warranty.

3.2.1 Lockout/Tagout

WARNING

Entanglement and crush hazard.

Keep all personnel clear of all moving components.

Verify all guards are in place.

Follow lockout/tagout procedure before performing service, inspections or maintenance.

Before performing service or maintenance:

- If Limb Beaver is connected to carrier:
 1. Park on a firm and level surface.
 2. Lower Limb Beaver to ground.
 3. Set parking brake.
 4. Stop engine and remove key.
 5. Place a Do Not Operate tag on control panel.
- If Limb Beaver is not connected to carrier:
 1. Verify Limb Beaver is on firm and level ground.

Safety

3.3 Safety Decals

Safety decals are located on the equipment to identify both operational and maintenance hazards.



These safety decals are placed according to the hazard in that area of the machine.

Read and understand each safety decal and the hazard it references.

These safety decals are additional information to the safety content already described in this section of the operator's manual.

All safety decals must be legible at all times. Keep them clean by using a mild soap and water, avoid using harsh chemicals or pressure washing. If the safety decal is no longer legible, replace it with a new one.

Contact Limb Beaver for new decals.



Decal A - LBD-002



Decal B - LBD-003



Setup

4. Setup

4.1 Hydraulic Hoses

LB 4SS: Limb Beaver is equipped with hoses to connect to skidsteer hydraulic system. Route hydraulic hoses in a safe location.

LB 4TR: Limb Beaver provides hoses to a bulk head connector or a valve (depending on configuration) on top of the frame. Male hydraulic quick couplers are provided. You must provide hoses from tractor to the bulk head connector or valve.

LB 4EX: Hoses to connect excavator to the Limb Beaver hydraulic system are not provided.

The motor supply and return hoses must be 3/4 in. high pressure hydraulic hose, 3000 psi or higher.

The case drain hose must be 3/8 in. high pressure hydraulic hose, 3000 psi or higher.

Refer to the excavator operators manual or contact the dealer for information on where the pressure, return and case drain couplers on carrier are located.

Hoses must be long enough to allow for tilting and folding of the unit, and fitted with a mated female coupler.

NOTICE



Prevent equipment damage.

Route hydraulic hoses in a safe location to avoid damage.

All Models: Perform an initial startup and carefully move Limb Beaver to all positions to verify hoses will not be damaged. Reroute if damage may occur.

4.2 Wireless Remote (If Equipped)

If equipped with a wireless remote control, verify batteries in control fobs are good and receiver battery is charged.



After removing fob for operation, close the electronics box being sure the foam padding is in place to protect components.

Operation

5. Operation

5.1 Attach To Carrier


⚠ WARNING

Prevent death or serious injury.


Do not attempt to operate Limb Beaver using forks through forklift pads.

Forklift pads are for handling and storage only.

Do not attempt to operate Limb Beaver using forks through forklift pads (A).



1. Verify the mount plate and receiver plate are free of any dirt or debris and that the locking mechanism pins rotate freely. Lubricate locking mechanism if necessary.
2. Skidsteer: Tilt carrier mount plate (B) forward. Position mount plate into the upper lip (C) of the receiver plate. Raise carrier loader arms slightly while tilting mount plate back at the same time. The Limb Beaver should be raised slightly off the ground with the mount plate (B) tilted all the way back.



Tractor: Attach Limb Beaver to tractor. See tractor operator's manual.

Excavator: Attach Limb Beaver to excavator. See excavator operator's manual.

3. Stop carrier engine.

⚠ WARNING

Crush hazard.

If locking mechanism pins are not fully seated, the Limb Beaver could fall off of the carrier, crushing you or bystanders.

Locking mechanism pins must be fully seated through the Limb Beaver receiver plate.

4. Skidsteer: Engage locking mechanism pins. Verify pins are fully seated through receiver plate.

Operation

Tractor: Verify pins are secure to lock Limb Beaver to tractor mount.

Excavator: Verify pins are secure to lock Limb Beaver to excavator mount.

WARNING

Pressurized fluids can penetrate the skin.

Hydraulic hoses can fail from age, damage and exposure.


Use body and face protection while searching for leaks. A tiny, almost invisible leak can penetrate the skin, thereby requiring immediate medical attention.

Use wood or cardboard to detect hydraulic leaks, never use your hands.

5. Route hydraulic hoses in a safe area away from pinch points and moving parts. Connect pressure, return and case drain hydraulic hoses. Confirm hydraulic connections are secure.
6. Verify hydraulic hoses are clear of pinch areas and moving parts.

5.2 Detach From Carrier

1. Position cutting head in vertical position and install pin (A). Install lynch pin through pin (A).
2. Stop carrier engine and relieve hydraulic pressure.
3. Lower Limb Beaver on to a flat level surface.
4. Move tilt frame to transport position and install pin (B) through brackets as shown. Install lynch pin through pin (B).



Transport Position - LB 4SS And LB 4TR

5. Disconnect hydraulic hoses.
6. Disengage locking mechanism pins.
7. Unlatch locks or pins and move carrier away from Limb Beaver.

Operation

5.3 Transporting

WARNING

Prevent death or serious injury.

Keep Limb Beaver close to the ground. Operation with a raised Limb Beaver may result in carrier rollover.

1. Raise Limb Beaver slightly off the ground.
2. Travel at a reasonable and safe speed.

5.4 Daily Inspections

Thoroughly inspect the Limb Beaver before each operation.

Verify all safety signs are in place and clearly visible.

Check for loose or missing parts and any damage that may have occurred during operation, moving or shipping.

Check cutting teeth for wear or damage. Replace worn or damaged cutting teeth.

Review all carrier pre-start instructions and verify that all recommended steps and procedures have been followed.

5.5 Operating Limb Beaver

5.5.1 Operational Safety

DANGER

Prevent electrocution.

Death or serious injury can result if equipment, tree or brush comes near or contacts power lines.

Electrocution can occur without direct contact.

WARNING

Prevent death or serious injury.

Only experienced and properly trained operators may operate carrier and Limb Beaver.

WARNING

Prevent death or serious injury.

Keep bystanders 300 feet away from Limb Beaver during operation.

WARNING

Entanglement and severing hazard.

Keep away from moving parts.

WARNING

Safety is the responsibility of the operator.

Verify your carrier's safety features, including ROPs and FOPs meet your job safety requirements.

Operation

WARNING

Moving parts can crush and dismember.

Disconnect and lockout power source before adjusting or servicing.

WARNING

Do not operate, work on or around Limb Beaver while under the influence of alcohol, prescription or nonprescription medication, or if feeling ill.

WARNING

Entanglement and severing hazard.

Disengage hydraulic flow and allow cutting head to stop before leaving operators seat.

WARNING

Prevent injury.

Do not stand next to cutting head when removing or installing transport pin.

Cutting head could fall when transport pin is removed or installed.

WARNING

Prevent death or serious injury.

Do not attempt to operate Limb Beaver using forks through forklift pads.

Forklift pads are for handling and storage only.

NOTICE


Prevent equipment damage.

If carrier is equipped with a low/high flow hydraulic system, operate Limb Beaver on low flow.


Operation

5.5.2 Machines With Manual Tilt And Swing


1. Read and understand Section 5.5.1 Operational Safety.
2. Attach Limb Beaver to carrier. See Section 5.1 Attach To Carrier.
3. Stop carrier engine.
4. Inspect work area for obstructions, power lines and other obstacles. Also inspect the area where the carrier will travel for holes, ruts and other obstacles that could effect the stability of the carrier.
5. Remove pin (A) and pins (B). Manually move tilt frame to desired working position.



6. Install pin (B) through appropriate holes in main frame and tilt frame. Install lynch pins (C) through pins (B). Tilt frame must be locked in position before operation.




7. Remove lynch pin (D) and transport pin (E).



8. Verify everyone is clear of the area, start carrier and move to an open area to test functions.

Operation

9. With carrier engine running at low idle, engage hydraulics. Operate cutting head to get a feel for the controls.
10. Move to work area and increase carrier engine speed to high idle and begin operation. Raise Limb Beaver and position cutting head as needed for desired cut. Travel at a slow pace. If cutting head stalls, stop carrier and allow head to regain speed before continuing operation.
11. When operation is completed, decrease carrier engine speed to low idle.
12. Disengage hydraulic flow and allow cutting head to stop.
13. Lower Limb Beaver to ground.
14. Install transport pin (E) and lynch pin (D).
15. Remove lynch pins (C) and pins (B).
16. Move tilt frame to the transport/storage position.
17. Install pin (A), pins (B) and lynch pins (C).




Transport/Storage Position

Operation

5.5.3 Machines With Hydraulic Tilt And/ Or Swing

1. Read and understand Section 5.5.1 Operational Safety.
2. Attach Limb Beaver to carrier. See Section 5.1 Attach To Carrier.
3. Stop carrier engine.
4. Inspect work area for obstructions, power lines and other obstacles. Also inspect the area where the carrier will travel for holes, ruts and other obstacles that could effect the stability of the carrier.
5. Move tilt frame and cutting head to desired working position.
6. Verify everyone is clear of the area, start carrier and move to an open area to test functions.
7. With carrier engine running at low idle, engage hydraulics. Operate cutting head to get a feel for the controls.
8. Move to work area and increase carrier engine speed to high idle and begin operation. Raise Limb Beaver and position cutting head as needed for desired cut. Travel at a slow pace. If cutting head stalls, stop carrier and allow head to regain speed before continuing operation.
9. When operation is completed, decrease carrier engine speed to low idle.
10. Disengage hydraulic flow and allow cutting head to stop.
11. Lower Limb Beaver to ground.
12. Move cutting head and tilt frame to the transport/ storage position.



Transport/Storage Position


Operation

5.5.4 Machines With Wireless Remote

1. Read and understand Section 5.5.1 Operational Safety.
2. Attach Limb Beaver to carrier. See Section 5.1 Attach To Carrier.
3. Stop carrier engine.
4. Inspect work area for obstructions, power lines and other obstacles. Also inspect the area where the carrier will travel for holes, ruts and other obstacles that could effect the stability of the carrier.
5. Verify everyone is clear of the area, start carrier and move to an open area to test functions.

Note: It is important to press fob button before engaging hydraulics. Cutting head will rotate if hydraulics are engaged before pressing fob button.


6. Press and hold button (A) on fob and engage carrier hydraulics to operate swing function. Position tilt frame in desired position. Move hydraulic control to neutral or off position and release button (A).



7. Press and hold button (B) on fob and engage carrier hydraulics operate tilt function. Position cutting head frame in desired position. Release button and move hydraulic control to neutral or off position and release button (B).

8. With carrier engine running at low idle, operate hydraulics (Remote fob is not used to operate cutting head rotation) to engage cutting head rotation.

Cutting head can rotate in both directions. Operate hydraulic flow so cutting head is turning counter clockwise when viewed from above.




9. Move to work area and increase carrier engine speed to high idle and begin operation. Raise Limb Beaver and position cutting head as needed for desired cut. Travel at a slow pace. If cutting head stalls, stop carrier and allow head to regain speed before continuing operation.
10. If a tilt or swing correction is needed during operation:
 - a. Disengage hydraulics.
 - b. Push and hold fob button (A) or (B).
 - c. Engage hydraulics to move cutting head or swing frame the desired position.
 - d. After desired position is achieved, disengage hydraulics and release fob button.
 - e. Engage hydraulics to continue cutting.
11. When operation is completed, decrease carrier engine speed to low idle.
12. Disengage hydraulic flow and allow cutting head to stop.


Note: It is important to press fob button before engaging hydraulics. Cutting head will rotate if hydraulics are engaged before pressing fob button.

Operation

13. Press and hold button (B) on remote and engage carrier hydraulics to operate tilt function. Position cutting head frame in vertical position. Release button and move hydraulic control to neutral or off position.



14. Press and hold button (A) on remote and engage carrier hydraulics to operate swing function. Position swing frame in retracted position. Release button and move hydraulic control to neutral or off position.



Transport/Storage Position

15. Lower Limb Beaver to ground.
16. Stop carrier engine and relieve hydraulic pressure.

Maintenance

6. Maintenance

⚠ WARNING

Entanglement and crush hazard.

Follow lockout/tagout procedure before performing service, inspections or maintenance.

Before performing service or maintenance:

- If Limb Beaver is connected to carrier:
 1. Park on a firm and level surface.
 2. Lower Limb Beaver to ground.
 3. Set parking brake.
 4. Stop engine and remove key.
 5. Place a Do Not Operate tag on control panel.
- If Limb Beaver is not connected to carrier:
 1. Verify Limb Beaver is on firm and level ground.

⚠ WARNING

Pressurized fluids can penetrate the skin.


Hydraulic hoses can fail from age, damage and exposure.

Use body and face protection while searching for leaks. A tiny, almost invisible leak can penetrate the skin, thereby requiring immediate medical attention.

Use wood or cardboard to detect hydraulic leaks, never use your hands.

6.1 Lubrication

Grease bearings with a general purpose grease.




Maintenance

6.2 Replace Cutting Teeth Or Drum Bearing


1. Be sure all teeth are aligned and locked into position. Align any tooth that has ramped up and is out of line before attempting to loosen lock nut. Failure to do so could result in the failure of some parts.
2. Lower cutting head to the ground. Stop engine and remove key. Place a Do Not Operate tag on control panel.

Note: During disassembly, note orientation and sequence of parts for reassembly.


3. Remove locknut (A), washer (B), bushing (C), bearing (D) and housing (E).



4. Remove teeth as needed to get to broken tooth. If broken tooth is below a bearing, that bearing will need to be removed, similar to bearing (D) and housing (E).



5. Apply anti-seize to exposed area of shaft.
6. Replace teeth with notched side of tooth (F) facing the drive motor. Verify teeth are interlocked together as shown. Always install new tooth for each tooth removed.



7. Install housing (E), bearing (D), bushing (C) washer (B) and locknut (A).
8. Tighten locknut to 420 lb-ft of torque.
9. Swing cutting head to transport position and disengage hydraulic flow.


Troubleshooting

7. Troubleshooting

PROBLEM	CHECK	SOLUTION
Cutting head does not spin.	Cutting head jammed.	Remove material from cutting head.
	Carrier oil level low.	Check oil level. Add if necessary.
	Carrier oil flow low.	Check flow control on carrier.
Cutting head rotates slow.	Carrier oil level low.	Check oil level. Add if necessary.
	Carrier oil filter plugged.	Replace oil filter.
	Carrier oil flow low.	Set relief pressure to motor specification. Contact your dealer.
Excessive vibration.	Cutting teeth worn or missing.	Replace worn, broken or missing teeth.
	Debris lodged in cutting head.	Remove debris.
Low cutting power.	Low carrier flow or pressure.	Check hydraulic pump flow and pressure. Contact your carrier dealer
Hydraulic function does not operate.	Valve selector lever is in the wrong position.	Move selector lever to other position.

Parts


8. Parts



Parts

Item	Part Number	Description	Qty
1	LB4	Swing Frame	1
2	LB4	Tilt Frame	1
3	LBH-038	Screen	1
4	LB4	Cutter Bar	1
5	97135A038	Locknut	1
6	LBH-112	Washer	1
7	LBH-031	Bearing Bushing	2
8	LBH-009	Bearing	2
9	LBH-137	Bearing Housing	2
10	LBH-034	Cutter Teeth	35
11	LBH-112	Shaft	1
12	LBH-021	Motor Shield	1
13	LBH-032-A	Spline Coupler	1
14	LBH-029	Pillow Block W/Bearing	1
15	LBH-032	Lower Drive Bushing	1
16	LBH-111	Locking Pin	1
17	LBH-019	Motor Mount Adapter Plate	1
18	90146A238	Pin	1
19	LBF-100	1 X 8 Inch Pin (LB 4 With Swing Cylinder)	1
	LBF-100	1 X 8 Inch Pin (LB 4 Without Swing Cylinder)	3
		Grease Fitting	3
	LBH-039A	15 GPM Motor	1
	LBH-039B	20 GPM Motor	1
	LBH-039C	30 GPM Motor	1
	LBH-039D	40 GPM Motor	1
	LBF-028	Hose Kit, 6 Ft, Complete	1
	LBF-028A	Hose, SS To Valve	1
	LBF-028B	Hose, Valve To Motor	1
	LBF-028C	Hose, Tilt Cylinder	1
	LBF-028D	Swing Cylinder Hoses	1
	LBF-029	Tilt Cylinder	1
	LBF-030	Swing Cylinder	1
	LBH-046	Pivot Pins	3
	LBH-009	Pivot Pin Bushing	3
	LBSS4-001	Valve	1
	LBH-155	Pin, Drive Coupler	1

Parts



Warranty

9. Warranty

Limb Beaver LLC warrants to the original purchaser that the product will be free from defects in material and workmanship for one year from the date of purchase by the original purchaser.

Under no circumstances will this warranty cover any claimed defective part or component, which, in the opinion of Limb Beaver LLC has been subjected to misuse, unauthorized modification or alteration, or to an accident.

Obligation of Limb Beaver LLC under this warranty shall be exclusive and be limited to repairing or replacing, free of charge, any part or component that, in the judgment of Limb Beaver LLC, shows evidence of such defect, provided further that such part shall be returned within thirty (30) days from date of failure to Limb Beaver LLC or its designee, transportation charges prepaid. This warranty does not cover any transportation costs.

Under no circumstances will Limb Beaver LLC be liable for any consequential damage or expense of any kind, including loss of profits. Limb Beaver LLC is under no circumstances liable for carrier unit damage of any kind. Limb Beaver LLC is not liable for the maintenance of the product. Limb Beaver LLC will not cover time to diagnose and repair compatibility issues between carrier and attachment.

Limb Beaver LLC reserves the right to make improvements or changes in design or manufacturing specifications at any time, without incurring any obligation to owners of units previously sold. No one is authorized to alter, modify or enlarge this warranty nor the exclusions, limitations and reservations.

Warranty



Limb Beaver LLC
3566 Robbins Nest Rd
Thompson's Station, TN 37179
844-697-5505
615-707-2278
www.LimbBeaver.com